

FIG. 1A




FIG. 1B




FIG. 1C

100




FIG. 10




FIG. 2A

EXTERNAL
FORWARD ADDR 278

Configuration Storage 250

Processor Control Register 252

Execution mode word 253

Isolated Setting Register 260

Mask Register 262

Isolated Mask Value 263

Base Register 264

Isolated Base Value 265

Length Register 266

Isolated Length Value 267

Isolated Subsystem Memory Range Settings Register 280

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

ID ₁	Entry Attributes	Subsystem Range Setting	Entry Context
ID ₂	Entry Attributes	Subsystem Range Setting	Entry Context

Operand
224

Isolated
Subsystem
Memory Range
Settings 281

Current Entry Context Configuration 275

Entry Frame Register 294

Entry Address 295

Current Subsystem Range Setting Configuration 273

Subsystem Mask Register 289

Subsystem Mask Value 290

Subsystem Base Register 291

Subsystem Base Value 292

Length Register 296

Subsystem Length Value 297

270
MULTI-MEMORY
ZONE
ACCESS
CHECKER
CIRCUIT

Processor
Isolated
Access 272

ACCESS
GRANT 274

PHYSICAL ADDRESS 282

READ /WRITE (RD/WR#) 284

ACCESS TYPE 286

ACCESS
INFORMATION
226





FIG. 3




FIG. 4